



KEYED NOTES:

- 1 FILL PIPE. PERMANENTLY MOUNTED ON TANK. SEE FILL PIPE DETAIL.
- 2 AIR GAP. AIR GAP IS TWICE THE DIAMETER OF FILL PIPE ABOVE FLOOD RIM.
- 3 HOSE CONNECTION.
- 4 FLOOD RIM.
- 5 FIRE HYDRANT METER.
- 6 APPROVED RPBA.
- 7 SUPPORTS REQUIRED.


RPBA = REDUCED PRESSURE BACKFLOW ASSEMBLY




WATER TRUCK WITH AIR GAP





FILL PIPE DETAIL WITH AIR GAP




WATER WAGON WITH AIR GAP



ELEVATED TANK WITH RPBA'S



TANK TRUCKS WITH RPBA'S



REVISIONS	NM APWA WATER
APPROVED METHODS OF FILLING TANKS	
DWG. 2395 FEB. 2006	